

IF09P/1

Interface for connecting max. 31 SIKO devices
with RS485 interface to Profibus DP

User manual




Table of contents

1	General Information	4
1.1	Documentation	4
1.2	Definitions	4
1.3	Intended use	5
1.4	Numerical data	5
2	Technical Data	5
2.1	Profibus interface (X5 connection)	5
2.2	Interface to SN4 or SN3, resp. (X3 or X4 connection, resp.)	6
2.3	Functioning	6
2.3.1	Starting phase	7
2.3.2	Operating phase	9
2.3.3	Parameterization/status query	9
2.4	Cycle times	10
2.5	Connection diagram	11
3	Operation	12
3.1	Protocol setting	12
3.2	Profibus address	13
3.3	Diagnostic and control functions	13
3.4	Configuration/project planning	14
3.5	Parameterization in the DATA-EXCHANGE state	15
3.6	Command list (index table)	17
3.6.1	Command list for the SN3 protocol	18
3.6.2	Command list for the SN4 protocol	19
3.7	Command output (flowchart)	20
3.7.1	Output position value parameter (SN3 and SN4 protocols)	20
3.7.2	Write/read calibration value parameter (SN3 and SN4 protocols)	20
3.7.3	Write/read offset parameter (SN3 protocol)	21
3.7.4	Read IF09P/1 device code parameter (SN3 and SN4 protocols)	21
3.7.5	Status / configuration parameter	22
3.7.5.1	Read status parameter (SN4 protocol)	22
3.7.5.2	Write configuration parameter (SN4 protocol)	24
3.7.5.3	Write/read counting direction parameter (SN3 protocol)	25
3.7.6	Write/read steps per revolution parameter (SN3 and SN4 protocols)	26
3.7.7	Read IF09P/1 status parameter (SN3 and SN4 protocols)	26
3.7.8	Calibration parameter (setting the position value to the calibration value) (SN3 and SN4 protocols)	27
3.7.9	Output/delete system status parameter (SN3 protocol)	27
3.7.10	Activate/deactivate incremental measurement parameter (SN4 protocol)	29
3.7.11	Write/read set point (SN3 and SN4 protocols)	29
3.7.12	Switch on keyboard (SN3 protocol)	30
3.7.13	Switch off keyboard (SN3 protocol)	30

3.7.14	Start positioning (SN3 protocol).....	31
3.7.15	Stop positioning (SN3 protocol)	31
3.7.16	Switch on display (SN3 protocol).....	31
3.7.17	Switch off display (SN3 protocol)	32
3.7.18	Set sense of rotation (SN4 protocol)	32
3.7.19	Read/program InPos window (SN3 protocol)	33
3.7.20	Read/program the loop reversal point	33
3.7.21	Read device code (SN3 protocol)	34
3.7.22	Read/program decimal places	34
3.7.22.1	Devices with SN4 protocol	34
3.7.22.2	Devices with SN3 protocol	35
3.7.23	Enable key's incremental measurement function (SN3 protocol)	36
3.7.24	Disable key's incremental measurement function (SN3 protocol)	36
3.7.25	Display divisor	37
3.7.25.1	Write with SN4 protocol.....	37
3.7.25.2	Read/write with SN3 protocol.....	37
3.7.26	Loop approach direction	38
3.7.26.1	Write with SN4 protocol.....	38
3.7.26.2	Read/write with SN3 protocol.....	38
3.7.27	Read/program Zeroing enable (SN3 protocol)	39
3.7.28	Write display orientation (SN4 protocol).....	39
3.7.29	Read/program display orientation and LED functionality (SN3 protocol).....	40
3.7.30	Enable key function (SN4 protocol).....	41
3.7.31	Incremental measurement and Reset key functions (SN4 protocol)	41
4	Trouble shooting	42
4.1	Error indication via status bytes	42
4.2	Error representation on the display	43

1 General Information

This user manual applies to the IF09P/1 PROFIBUS-gateway with firmware version 3.00 or higher! It describes the interface, its parameterization and commissioning.

The IF09P/1 Profibus gateway couples SIKO position encoders with SIKONETZ3- (SN3) or SIKONETZ4- (SN4) interfaces to the PROFIBUS-DP. Mixed operation of SIKONETZ4 and SIKONETZ3 instruments is not possible. The two interface protocols, the PROFIBUS station address as well as some diagnostic functions can be selected comfortably via the IF09P/1 keyboard.

1.1 Documentation

The following documents are associated with this document:

- The data sheet describes the technical data, the dimensions, the pin assignment, the accessories and the order key.
- The installation instructions describe the mechanical and electrical installation with all safety-relevant conditions and the associated technical specifications.
- The User manual for commissioning.

You can also download these documents at <http://www.siko-global.com/p/if09p-1>.

1.2 Definitions

NOTICE	This symbol precedes passages in the text that should be read particularly carefully in order to ensure the intended use of the device and to exclude dangers.
---------------	--

LB	Low-Byte, low-order byte
MB	Middle-Byte, middle-order byte
HB	High-Byte, higher-order byte
SN3	<u>SIKONETZ3</u> , bus-compatible data transmission protocol defined by SIKO (2 telegram formats, 19200 bit/s).
SN4	<u>SIKONETZ4</u> , bus-compatible data transmission protocol defined by SIKO (1 telegram format, 115200 bit/s).
DP	Distributed periphery
DPM1	DP master (class 1). The DPM1 is the central automation device with Profibus DP.
GSD	<u>Geräte-Stamm-Datei</u> . Electronic device data sheet in a pre-defined form for PROFIBUS devices.

1.3 Intended use

NOTICE	The IF09P/1 gateway is a high-quality electronic device. It serves exclusively for gathering and transferring position and / or parameterization data of connected SIKO devices to a PROFIBUS control. The gateway must be used exclusively for this purpose.
---------------	---

1.4 Numerical data

If not explicitly stated otherwise, decimal values are given as figures without an extension (e. g., 1234), binary values are marked with a "b" behind the figure (e. g., 19011b), hexadecimal values with an "h" (e. g., 280h).

2 Technical Data

- Max. 31 devices with SN3 or SN4 protocols can be connected
- Current supply 24 V DC $\pm 20\%$
- Power input ~ 1.3 W
- Galvanically isolated DP interface
- Profibus functionality via Siemens SPC3 Controller
- Bit rate on encoder side 19.2 kBit/s (SN3) or 115.2 kBit/s, resp. (SN4)
- Bit rate on Profibus side between 9.6 kBit/s and up to 12 Mbit/s
- Quick status diagnosis via LED status display
- Configurable via integrated keyboard and 5-digit 7-segment display
- Diagnostic functions

2.1 Profibus interface (X5 connection)

The IF09P/1 is connected to the Profibus via a 9-pin D-SUB connector according to EN 50170. If bus termination is required it should be in the connector; i. e., use appropriate connectors with terminating resistors that can be switched in. The following data rates are supported: 9.6 kBit/s, 19.2 kBit/s, 93.75 kBit/s, 187.5 kBit/s, 500 kBit/s, 1.5 MBit/s, 3 MBit/s, 6 MBit/s und 12 Mbit/s. The associated SIK000EC.GSD device database file available for download at www.siko-global.com contains additional Profibus-specific parameters.

For the D-Sub connector's pin configurations please refer to the pin layout below (see chapter 2.5).

2.2 Interface to SN4 or SN3, resp. (X3 or X4 connection, resp.)

You can choose either of the two D-Sub connectors, X3 or X4 for connecting the encoders. The maximum baud rate is 115.2 kBit/s for the SN4 protocol or 19.2 kBit/s for the SIKONETZ3 protocol. The connected encoders can be supplied directly via two additional pins. Supply current must not exceed 0.75 A! Refer to the connection diagram for the pin configuration (see chapter 2.5).

If the electricity requirements of the station connected to the IF09P/1 exceeds the above value, these devices shall be supplied via an external power pack. Take care that the external power pack and IF09P/1 have common earth connection!

2.3 Functioning

NOTICE	It is not mandatory that the encoder addresses start ascending with address 1; they may be assigned freely in the address range of 1 ... 31; however, avoid address conflicts by double or multiple assignment of identical addresses!
---------------	--


NOTICE	Note for S7 users: The functional building block SFC14 "DPRD_DAT" (SFC15 "DPWR_DAT") is required to enable consistent reading (writing) of these data!
---------------	--

After switching on, the IF09P/1 determines the number of encoders connected. The addresses of the stations found are entered into a table in ascending order.

In the data exchange phase, the position values of the encoders detected will then be transferred to the PLC (e. g., SIEMENS S7) in a data telegram with a length of up to 132 bytes.

A control/status telegram of 8 byte length supplied by the IF09P/1 itself is always prefixed to the position values. The encoders can be parameterized via these control bytes or status information can be read, respectively.

The outline below is intended to illustrate the structure of the data telegram. A configuration with 5 encoders serves as an example:



Three status LEDs inform about the interface's operational state:

- Green LED: Power on (operating voltage applied)
- Red LED: A failure occurred (blinking LED)
- Yellow LED: Ongoing data exchange between IF09P/1 and PLC master

In case of failure, the 5-digit display informs about the encoder that causes the error(s).

The keyboard serves for entering parameter values directly relating to the IF09P/1 and also for diagnosis of the encoders recognized by IF09P/1.


2.3.1 Starting phase

On the condition that all devices, IF09P/1 and the encoders (SN4 or SN3 stations, resp.) are switched on together¹, the following switch-on sequence will take place:

- The encoders initialize.
- The IF09P/1 goes through the initialization sequence shown below:

¹ It should be avoided to switch on the IF09P/1 before switching on the connected encoders because otherwise the encoders would not be identified correctly or not identified at all! Subsequent re-initialization with repeated scanning operation is only possible by entering a defined control code IFP09/1. For the description refer to chapter 3.3.

The opposite case of first starting the encoder and subsequently the IF09P/1 is possible without problems.



If no correct initialization takes place, corresponding error codes are displayed via the seven-segment display:

Displayed error code	Meaning
Pb001	Memory range exceeded.
Pb002	SPC3 is not in offline state.
Pb003	Error in Din/Dout length.
Pb004	Error in diagnosis length.
Pb005	Error in parameterization data length.
Pb006	Error in configuration data length.
Pb007	Error in address data length
Pb008	Other errors
Pb009	Other errors
Pb010	Error in IO length management.
Pb011	Error in pointer management.

2.3.2 Operating phase

NOTICE	If the IF09P/1 has been set to the SN3 protocol operating mode, then error messages output by the addressed encoders will be indicated transiently on the display (F02, F03 or F05 error messages; for details on the error messages refer to the relevant User information; see also chapter 4.1).
---------------	---

Having correctly completed the initialization sequence shown above, the IF09P/1 will cyclically fetch the position data of the encoders recognized and provides them to the IC SPC3 Profibus protocol.

Errors detected during this phase (transfer errors, checksum errors) are indicated on the display by a blinking red error LED and additionally as plain text with indication of the faulty encoder's address.

2.3.3 Parameterization/status query

NOTICE	The user shall ensure that the command telegram output by the PLC master will be removed from PROFIBUS immediately after acknowledgement of a parameterization or status query event, since otherwise the IF09P/1 gateway will be strongly impeded by permanent parameterization or status query events in cyclic position value query!
---------------	---


The PLC user can parameterize the encoders connected via the IF09P/1 or query the values of parameters. The interface expects receiving a parameterization telegram of 8byte length, which contains the parameter command, the address of the encoder to be addressed and the data proper for the encoder to be addressed.

If the PLC sends a parameterization telegram to the IF09P/1, the position value query will be suppressed until the parameter query has been processed. The PLC will be informed about the end of the query via a confirmation code (see [Table 1](#)).

The time between two parameter telegrams must not be shorter than 20 ms in order to enable correct saving of the values in the encoder internal EEPROMs.

2.4 Cycle times


The timing of the position value query and of Profibus interface operation is illustrated in the diagram below (SN4 protocol!):



The times marked with ^x are extended to ~5 ... 6 ms with SIKONETZ3 operation.

The times shown above apply to the simplest system structure with one encoder connected. The times indicated for position value query and Profibus operation will be extended by ~0.16 ms for every additional encoder connected.

2.5 Connection diagram



Sensor X3 and X4 connection	
Pin	Designation
1	+UB (with max. 0.75 A load!)
3	DÜA
5	GND
8	DÜB
2, 4, 6, 7, 9	nc

Profibus X5 connection	
Pin	Designation
3	B-Line
4	RTS
5	2M
6	2P5
8	A-Line
1, 2, 7, 9	nc

Operating voltage X1 connection	
Pin	Designation
1	PE
2	0 V
3	+24 V DC $\pm 20\%$

3 Operation

After removing the transparent cover, you can parameterize the IF09P/1 via the keyboard. The 5-digit LED display provides the user with the relevant information. The 4 keys have the following functions:

P- key:

By holding down this key for >5 sec. the parameter mode will be activated. The name of the parameter and its current value are displayed alternately. By pressing the key once more you will be led through the whole menu consisting of three parameters. Having arrived at the third parameter, repeated pressing of the P key will return you to normal operation. If no key is pressed for 30 seconds during parameterization, the F09P/1 will automatically return to normal operation.

Parameter 1: Protocol setting

Parameter 2: Address setting of Profibus station

Parameter 3: Diagnostic functions

Left arrow key:

Selection of digit to be changed.


Up arrow key:

Selection of digits 0 ... 9.


Asterisk key:

Adopting/saving the value selected by means of the arrow key.




3.1 Protocol setting

On the display, the *PrOt* value alternates with protocol name set. The protocols shown below can be set via the  key:

Sn4, Sn3


Acknowledge via the  key. The value will be adopted with the next restart.

3.2 Profibus address

On the display, the P_Adr value alternates with the address set. The address can be set in the 0 ... 125 range by pressing the  and  keys. Acknowledge by pressing the  key. The value will be adopted with the next restart.

3.3 Diagnostic and control functions

On the display, the $_Code$ value alternates with the 00000 , sequence of digit, with the active digit position blinking. Now, you may use the arrow keys to enter combinations of figures as shown below:

Control code	Description
$00\ 100$	<p>The position values of the encoders found are displayed. The display alternates between the address of the first encoder found and its position value in a 2-sec rhythm.</p> <p>You can switch forward to the next encoder by means of the  key. Having arrived at the encoder with the highest address, the value and address of the first encoder will be displayed after the next keystroke.</p> <p>In this operating mode, the encoder position values continue to be updated and transferred via the Profibus.</p> <p>You can leave this mode by pressing the P-key.</p>
00200	<p>In this operating mode, information on the data transfer quality is displayed on the encoder side. 3 values are displayed in succession:</p> <p>$tCErr$: Number of corrupt data telegrams (value range: 00000 ... 99999)</p> <p>t_nr: Overall number of data transfer events since switching on the IF09P/1</p> <p>$dtErr$: percentage representation of the relationship of $tCErr/t_nr$ (max. 99.999 %, min. 00.001 %)</p> <p>The number of data transfer events is displayed in the exponential format. However, the full number range cannot be displayed for greater values due to the limitation to 5-digit places. The following display ranges apply:</p> <p>$00\ 1E0 \dots 999E0$ Number <1000</p> <p>$00\ 1E3 \dots 999E3$ 1000 < Number <999999</p> <p>$00\ 1E6 \dots 999E6$ 1000000 < Number <999999999</p> <p>$00\ 1E9 \dots 004E9$ 1000000000 < Number <4293967296</p>
$11\ 100$	<p>This code initiates restart with resetting the Profibus address and the protocol type to their default values (Profibus_Address = 1, Protocol = SN4).</p>
$10\ 110$	<p>This code triggers a restart. The values set for Profibus address and protocol are maintained.</p>

3.4 Configuration/project planning

For the PROFIBUS-DP gateway a device database file named SIK000EC.GSD has been created. This file can be included in the device library by means of the configuration tool used for the procedure to be applied please refer to the documentation of the configuration tool.

The procedure for integrating the IF09P/1 into a Profibus unit will be described below based on the example of the IF09P/1 configuration with 5 encoders (see chapter 2.3). The hardware manager of the S7 configuration tool shall be used. The following conditions are assumed:

1. The device database file (SIK000EC.GSD) is in the correct directory.
2. At least 1 master module was selected.


1st step:

Selection of the Profibus station to be included (here: Gateway IF09P/1). It is found in the device catalogue under the path "Profibus-DP\Additional field devices\Gateway".


2nd step:

The modules presented are positioned on the slots shown via drag & drop.

IMPORTANT NOTE: The "parameter in/out" module must always be placed on the first place!



The modules "position sensor no. XX" (XX = 01 ... 31) represent the storage locations where the position values of the encoders connected to the IF09P/1 are stored.



3.5 Parameterization in the DATA-EXCHANGE state

Usually, parameterization of a slave is carried out once in the start-up phase only. The parameters are determined during configuration by means of a suitable software tool.


PROFIBUS-DPV0 is not designed for slave parameterization during the DATA EXCHANGE phase (Acyclic data exchange between master and slave is possible from PROFIBUS-DPV1 onwards).

Since the IF09P/1 is based on DPV0, the possibility of overcoming this limitation was provided in order to enable reprogramming of the gateway-linked encoders also during on-going operation.

For this purpose, an input/output range of 8byte has been reserved, which is marked "parameter in/out" in the configuration. The PLC user transfers parameterization data and receives diagnostic and status messages via this range.


All 8 bytes are set to the 0 value during regular data exchange operation.

Structure of the first 8 bytes of the data telegram



Structure of the subsequent bytes of the data telegram (position values):

(Bytes $8 + n*4$; $n = 1 \dots 31$)



Byte 1: Command code

Command (Service)	Command code (hexadecimal)	Command code (decimal)	Meaning
Write Request	23h	35	send parameter to IF09P/1 gateway
Write Response	60h	96	response of the IF09P/1 gateway to Write Request
Read Request	40h	64	parameter request of the IF09P/1 gateway
Read Response	42h	66	response to the request with current value
Error Response	80h	128	error message

Table 1: Command codes

Byte 2, 3: Parameter index

The parameter index is entered in the user data byte 2 (low byte) and in the user data byte 3 (high byte) using the Intel data format (see chapter 3.6.1 or 3.6.2).

Byte 4: Address

This is the position of the address of the encoder to be parameterized. The values are in the range of 1 ... 31. Address value 0 is reserved for the IF09P/1.

The following statement applies only if the SIKONETZ3 protocol has been set:

Bit 6 controls the broadcast whether a command is to apply to all stations or not. With the bit set (= 1), the address (of the SIKONETZ3 station) is ignored and the command sent to all devices. With value 0, broadcasting bit is ignored and only the device with the indicated address addressed. For broadcast-compatible commands, please refer to the command list (see chapter 3.6.1).

Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
0	broadcast bit	0	Address 1 ... 31				

Table 2: Broadcast

Byte 5 ... 8: data byte 1 ... data byte 4

In the data range, the value of the parameter is entered in left-aligned Intel notation. (Byte 5 = Low Byte ... Byte 8 = High Byte)

3.6 Command list (index table)

Since the commands for devices with SN3 protocol differ in some regard from those with SN4 protocol, we have listed two sets of commands below.

3.6.1 Command list for the SN3 protocol

Parameter	Parameter index	Address	Data type	Data length	Access	see chapter
Position value	5F00h	1 ... 31	Integer32	4	R	3.7.1
Calibration value	5F01h	1 ... 31	Integer32	4	R/W	3.7.2
Offset ²	5F02h	1 ... 31	Integer32	4	R/W	3.7.3
Device code IF09P/1	5F03h	0	Integer32	4	R	3.7.4
Sense of rotation (counting direction)	5F04h	1 ... 31	Integer32	4	R/W	3.7.5.3
Steps per revolution ²	5F05h	1 ... 31	Integer32	4	R/W	3.7.6
IF09P/1 status	5F06h	0	Integer32	4	R	3.7.7
Calibration (setting the position value to the calibration value)	5F07h	1 ... 31	Integer32	4	W ³	3.7.8
System status of SN3 encoder	5F08h	1 ... 31	Integer32	4	R/W ³⁴	3.7.9
Not implemented (causes error message)	5F09h	-	-	-	-	-
Set point	5F0Ah	1 ... 31	Integer32	4	R/W	3.7.11
Switch on keyboard ²³⁵	5F0Bh	1 ... 31	Integer32	4	W ³	3.7.12
Switch off keyboard ²³⁵	5F0Ch	1 ... 31	Integer32	4	W ³	3.7.13
Start positioning ²³	5F0Dh	1 ... 31	Integer32	4	W ³	3.7.14
Stop positioning ²³⁵	5F0Eh	1 ... 31	Integer32	4	W ³	3.7.15
Switch on display ²³⁵	5F0Fh	1 ... 31	Integer32	4	W ³	3.7.16
Switch off display ²³⁵	5F10h	1 ... 31	Integer32	4	W ³	3.7.17
InPos window	5F11h	1 ... 31	Integer32	4	R/W	3.7.19
Loop reversal point	5F12h	1 ... 31	Integer32	4	R/W	3.7.20
Encoder device code	5F13h	1 ... 31	Integer32	4	R	3.7.21
Decimal places	5F14h	1 ... 31	Integer32	4	R/W	3.7.22.2
Enable key's incremental measurement function	5F15h	1 ... 31	Integer32	4	W ³	3.7.23
Disable key's incremental measurement function	5F16h	1 ... 31	Integer32	4	W ³	3.7.24
Display divisor	5F17h	1 ... 31	Integer32	4	R/W	3.7.25.2
Loop approach direction	5F18h	1 ... 31	Integer32	4	R/W	3.7.26.2
Zero enable	5F19h	1 ... 31	Integer32	4	R/W	3.7.27
Display orientation and LED functionality	5F1Ah	1 ... 31	Integer32	4	R/W	3.7.29

² This parameter is not implemented with all devices.

³ The content of the user data bytes is irrelevant.

⁴ Write access deletes the system status of the addressed encode.

⁵ These commands are broadcast compatible.

3.6.2 Command list for the SN4 protocol

Parameter	Parameter index	Address	Data type	Data length	Access	see chapter
Position value	5F00h	1 ... 31	Integer32	4	R	3.7.1
Calibration value	5F01h	1 ... 31	Integer32	4	R/W	3.7.2
Not implemented (causes error message)	5F02h	-	-	-	-	-
Device code IF09P/1	5F03h	0	Integer32	4	R	3.7.4
Read status	5F04h	1 ... 31	Integer32	4	R	3.7.5.1
Write configuration	5F04h	1 ... 31	Integer32	4	W	3.7.5.2
Steps per revolution	5F05h	1 ... 31	Integer32	4	R/W	3.7.6
IF09P/1 Status	5F06h	0	Integer32	4	R	3.7.7
Calibration (setting the position value to the calibration value)	5F07h	1 ... 31	Integer32	4	W ³	3.7.8
Not implemented (causes error message)	5F08h	-	-	-	-	-
Incremental measurement	5F09h	1 ... 31	Integer32	4	W ³	3.7.10
Target value	5F0Ah	1 ... 31	Integer32	4	W	3.7.11
Not implemented (causes error message)	5F0Bh	-	-	-	-	-
Not implemented (causes error message)	5F0Ch	-	-	-	-	-
Not implemented (causes error message)	5F0Dh	-	-	-	-	-
Not implemented (causes error message)	5F0Eh	-	-	-	-	-
Not implemented (causes error message)	5F0Fh	-	-	-	-	-
Not implemented (causes error message)	5F10h	-	-	-	-	-
Write sense of rotation (counting direction)	5F11h	1 ... 31	Integer32	4	W	3.7.18
Write decimal places	5F12h	1 ... 31	Integer32	4	W	3.7.22.1
Write display divisor	5F13h	1 ... 31	Integer32	4	W	3.7.25.1
Write loop approach direction	5F14h	1 ... 31	Integer32	4	W	3.7.26.1
Write display orientation	5F15h	1 ... 31	Integer32	4	W	3.7.28
Write enable key function	5F16h	1 ... 31	Integer32	4	W	3.7.30
Enable/disable "Incremental measurement" and "Reset" key functions	5F17h	1 ... 31	Integer32	4	W	3.7.31

Access = R: Read access enabled only.


Access = W: Write access enabled only.

Access = R/W Write and Read access enabled.

All values are represented in the Intel format (the lowest-value byte first).

3.7 Command output (flowchart)

The flowchart below demonstrates the fundamental process of parameterization:



3.7.1 Output position value parameter (SN3 and SN4 protocols)

This parameter is present for the sake of completeness only. The position or display values of the connected encoders are always transferred to the Profibus master during the Data Exchange phase.

By executing this command, a specific encoder is addressed. This parameter is read-only, write access is acknowledged with an error message.

Example of a call: Read position value of encoder with addr. 5.

Command code	Param. index Low	Param. index High	Sub-index (= address)	Data byte 1	Data byte 2	Data byte 3	Data byte 4
40h	00h	5Fh	05h	00h	00h	00h	00h

Reply: Position value = 3A6579h (= 3.827.065)

Command code	Param. index Low	Param. index High	Sub-index (= address)	Data byte 1	Data byte 2	Data byte 3	Data byte 4	Position values of the connected encoders	
42h	00h	5Fh	05h	79h	65h	3Ah	00h	xxh	xxh

3.7.2 Write/read calibration value parameter (SN3 and SN4 protocols)

NOTICE	By writing the calibration value, the addressed encoder's position value will not be set to this value yet! The position value is set to the calibration value after execution of the command with parameter index 5F0H only (see chapter 3.7.8).
---------------	---

This parameter reads or writes the calibration value of the addressed encoder.

When writing the calibration value, the value range of the addressed encoder must be observed!

Example of a call: Set calibration value of encoder with addr. 22 to 10000h.

Command code	Param. index Low	Param. index High	Sub-index (= address)	Data byte 1	Data byte 2	Data byte 3	Data byte 4
23h	01h	5Fh	16h	00h	00h	01h	00h

Reply:

Command code	Param. index Low	Param. index High	Sub-index (= address)	Data byte 1	Data byte 2	Data byte 3	Data byte 4	Position values of the connected encoders	
60h	01h	5Fh	16h	00h	00h	01h	00h	xxh	xxh

3.7.3 Write/read offset parameter (SN3 protocol)

A certain figure (offset) can be added to the position or display value, resp. Positive as well as negative values are permitted.

Example of a call: Set offset value of encoder with addr. 12 to 360 (= 0168h).

Command code	Param. index Low	Param. index High	Sub-index (= address)	Data byte 1	Data byte 2	Data byte 3	Data byte 4
23h	02h	5Fh	0Ch	68h	01h	00h	00h

Reply:

Command code	Param. index Low	Param. index High	Sub-index (= address)	Data byte 1	Data byte 2	Data byte 3	Data byte 4	Position values of the connected encoders	
60h	02h	5Fh	0Ch	00h	00h	00h	00h	xxh	xxh

3.7.4 Read IF09P/1 device code parameter (SN3 and SN4 protocols)

This parameter is read-only, write access is acknowledged with an error message.

Data byte 1: Coding of the IF09P/1 device (07h).

Data byte 2: Version number (30h for V3.00).

Data byte 3: Hardware version (0 = IF09P, 1 = IF09P/1).

Data byte 4: Occupied with 0.

Example of a call: Read IF09P/1 device code.

Command code	Param. index Low	Param. index High	Sub-index (= address)	Data byte 1	Data byte 2	Data byte 3	Data byte 4
40h	03h	5Fh	00h	xxh	xxh	xxh	xxh

Reply:

Command code	Param. index Low	Param. index High	Sub-index (= address)	Data byte 1	Data byte 2	Data byte 3	Data byte 4	Position values of the connected encoders	
42h	03h	5Fh	00h	07h	30h	01h	00h	xxh	xxh

3.7.5 Status / configuration parameter

3.7.5.1 Read status parameter (SN4 protocol)

With this function, the following information is read from an addressed device. For detailed information on the terms listed below please refer to the relevant User information of the connected devices:


- Battery status
- Key mode
- Version number
- Display orientation
- "Incremental measurement and Reset" key mode
- Loop approach direction
- Sense of rotation (counting)
- Decimal places
- Display divisor or LED function, resp.

Data byte 4: always 0


Data byte 3: Version number (e. g. AP05-SW06: V1.04 = 68h)

0	1	1	0	1	0	0	0
---	---	---	---	---	---	---	---

Data byte 2: Number of decimal places (0 ... 3), Display divisor or LED function, resp., loop approach direction



Data byte 1: Battery status, key mode, display orientation, sense of rotation



Example of a call: Read status of encoder with addr. 17.

Command code	Param. index Low	Param. index High	Sub-index (= address)	Data byte 1	Data byte 2	Data byte 3	Data byte 4
40h	04h	5Fh	11h	00h	00h	00h	00h

Reply: Battery discharged, key mode = reset, display orientation = 0°, counting direction = descending, 2nd decimal place, version 1.04.

Command code	Param. index Low	Param. index High	Sub-index (= address)	Data byte 1	Data byte 2	Data byte 3	Data byte 4	Position values of the connected encoders	
42h	04h	5Fh	11h	A1h	02h	68h	00h	xxh	xxh

3.7.5.2 Write configuration parameter (SN4 protocol)

NOTICE	Prior to executing this function, the user must get and evaluate the encoder's current status. Afterwards, the desired operation can be executed by setting/deleting the appropriate bits in data bytes 1 and 2!
---------------	--


This function influences various encoder functions.

- Battery status
- Key mode
- Version number
- Display orientation
- "Incremental measurement and Reset" key mode
- Loop approach direction
- Sense of rotation (counting)
- Decimal places
- Display divisor or LED function, resp.


Data byte 4: not relevant (can contain any value)

Data byte 3: not relevant (can contain any value)

Data byte 2: Number of decimal places (0 ... 3), Display divisor or LED function, resp., loop approach direction



Data byte 1: Display orientation, key mode, sense of rotation (counting), enable/disable incremental measurement, reset function



Example call: The sensor AP05-SW06 (Adr. 17) should be parameterized in such a way that it displays 2 decimal places, the loop approach direction should be clockwise, the display divisor is set to 1, the display orientation is set to 0°, the key function is controlled according to the bits 4 and 5, the chain dimension function is executed when the key is pressed and the counting direction is down.

Command code	Param. index Low	Param. index High	Sub-index (= address)	Data byte 1	Data byte 2	Data byte 3	Data byte 4
40h	04h	5Fh	11h	11h	42h	00h	00h

Reply:

Command code	Param. index Low	Param. index High	Sub-index (= address)	Data byte 1	Data byte 2	Data byte 3	Data byte 4	Position values of the connected encoders	
42h	04h	5Fh	11h	00h	00h	00h	00h	xxh	xxh

3.7.5.3 Write/read counting direction parameter (SN3 protocol)

Parameter (data byte 1)	Rotary encoder	Linear encoder
00h	Ascending numerical values with clockwise (CW) rotation.	Ascending numerical values with sensor movement into connector outlet direction.
01h	Ascending numerical values with counterclockwise (CCW) rotation.	Descending numerical values with sensor movement into connector outlet direction.

Data bytes 2, 3, and 4 are not relevant and can have any values.

Example of a call: Set clockwise counting direction of encoder with addr. 17.

Command code	Param. index Low	Param. index High	Sub-index (= address)	Data byte 1	Data byte 2	Data byte 3	Data byte 4
23h	04h	5Fh	11h	00h	00h	00h	00h

Reply:

Command code	Param. index Low	Param. index High	Sub-index (= address)	Data byte 1	Data byte 2	Data byte 3	Data byte 4	Position values of the connected encoders	
60h	04h	5Fh	11h	00h	00h	00h	00h	xxh	xxh

3.7.6 Write/read steps per revolution parameter (SN3 and SN4 protocols)

This parameter serves for scaling the measuring range of a rotary encoder. SIKO encoders always interpret value 0 as maximum value. Values exceeding the number predefined by the encoder resolution cause sequences of steps >1.

Example of a call: Read number of steps per revolution from encoder with addr. 9.

Command code	Param. index Low	Param. index High	Sub-index (= address)	Data byte 1	Data byte 2	Data byte 3	Data byte 4
40h	05h	5Fh	09h	00h	00h	00h	00h

Reply: number of steps per revolution = 3600_{dec} (= 0E10_{hex}).

Command code	Param. index Low	Param. index High	Sub-index (= address)	Data byte 1	Data byte 2	Data byte 3	Data byte 4	Position values of the connected encoders	
42h	05h	5Fh	09h	10h	0Eh	00h	00h	xxh	xxh

3.7.7 Read IF09P/1 status parameter (SN3 and SN4 protocols)

The status of the IF09P/1 is mapped to the user data bytes 1 ... 4. In byte 1, value 1 represents OK and 0 not ready. In byte 2, the number of the connected encoders is output (value range 0 ... 31), bytes 3 and 4 are assigned 0.

Data byte 1: 0 ⇒ gateway not ready; 1 ⇒ gateway ready for data exchange

Data byte 2: number of encoders connected to the gateway

Data byte 3, 4: occupied with value 0

Example of a call:

Command code	Param. index Low	Param. index High	Sub-index (= address)	Data byte 1	Data byte 2	Data byte 3	Data byte 4
40h	06h	5Fh	00h	00h	00h	00h	00h

Reply: IF09P/1ready, 31 SIKONETZ stations available.

Command code	Param. index Low	Param. index High	Sub-index (= address)	Data byte 1	Data byte 2	Data byte 3	Data byte 4	Position values of the connected encoders	
42h	06h	5Fh	00h	01h	1Fh	00h	00h	xxh	xxh

3.7.8 Calibration parameter (setting the position value to the calibration value) (SN3 and SN4 protocols)

This serves for setting the addressed encoder to the calibration value. The data in user data bytes 1 ... 4 are not relevant and can be set to any values.

Example of a call: Encoder with address13 (0Dh) is to be set to the calibration value.

Command code	Param. index Low	Param. index High	Sub-index (= address)	Data byte 1	Data byte 2	Data byte 3	Data byte 4
23h	07h	5Fh	0Dh	00h	00h	00h	00h

Reply:

Command code	Param. index Low	Param. index High	Sub-index (= address)	Data byte 1	Data byte 2	Data byte 3	Data byte 4	Position values of the connected encoders	
60h	07h	5Fh	0Dh	00h	00h	00h	00h	xxh	xxh

3.7.9 Output/delete system status parameter (SN3 protocol)

NOTICE	The bits identified with * are encoder-dependent, refer to the relevant User information for the corresponding meaning!
---------------	---

This parameter serves for querying or deleting the status of the addressed SN3 station.

Data byte 1:

- Bit 0: Actuator 1 On *
- Bit 1: Actuator 2 On *
- Bit 2: Actuator 3 On *
- Bit 3: Position value frozen
- Bit 4: Keyboard switched on *
- Bit 5: Programming state on
- Bit 6: Limit comparison active *
- Bit 7: Blockage monitoring active *

Data byte 2:

- Bit 0: Error F01 occurred (display overflow) *
- Bit 1: Error F02 occurred (data transfer error, CRC error)

- Bit 2: Error F03 occurred (illegal or unknown command)
- Bit 3: Error F05 occurred (illegal value input)
- Bit 4: *
- Bit 5: *
- Bit 6: *
- Bit 7: Axle was blocked *

Data byte 3:

- Bit 0: Target value achieved *
- Bit 1: Break-over point reached *
- Bit 2: *
- Bit 3: *
- Bit 4: Lower limit reached *
- Bit 5: Upper limit reached *
- Bit 6: *
- Bit 7: On-going positioning *

A set bit (= 1) means active. Bits 0 to 7 of data byte 1 cannot be deleted by a write request of the System status command and are always up to date. Bits 0 ... 7 (byte2) and 0 ... 7 (byte3) are set automatically but must be deleted with a write request of the System status command.


Example of a call: Read system status of encoder with addr. 7.

Command code	Param. index Low	Param. index High	Sub-index (= address)	Data byte 1	Data byte 2	Data byte 3	Data byte 4
40h	08h	5Fh	07h	00h	00h	00h	00h


Reply:

Command code	Param. index Low	Param. index High	Sub-index (= address)	Data byte 1	Data byte 2	Data byte 3	Data byte 4	Position values of the connected encoders	
42h	08h	5Fh	07h	11h	00h	82h	00h	xxh	xxh

Meaning of the data bytes:



Data byte 2: no active status messages



3.7.10 Activate/deactivate incremental measurement parameter (SN4 protocol)

NOTICE The interval of two subsequent "Activate/deactivate incremental measurement" commands must be >100 ms!

This parameter serves for activating or deactivating the addressed encoder's incremental measurement function. The data in the user data bytes 1 ... 4 are not relevant and can be set to any values.

Example of a call: Incremental measurement function is to be activated in the encoder with address 14 (0Eh).

Command code	Param. index Low	Param. index High	Sub-index (= address)	Data byte 1	Data byte 2	Data byte 3	Data byte 4
23h	09h	5Fh	0Eh	xxh	xxh	xxh	xxh

Reply:

Command code	Param. index Low	Param. index High	Sub-index (= address)	Data byte 1	Data byte 2	Data byte 3	Data byte 4	Position values of the connected encoders	
60h	09h	5Fh	0Eh	00h	00h	00h	00h	xxh	xxh

Another call of this function will deactivate the incremental measurement function again!

3.7.11 Write/read set point (SN3 and SN4 protocols)

This command is used in connection with positioning tasks. The desired position value to be travelled to (= set point) is programmed and put into operation via the Start positioning command described below (see chapter 3.7.14).

An appropriate system structure, e. g., with a type AP05-SW06 SIKONETZ rotary encoder is the precondition for this procedure. With the SN4 protocol set, a read access will result in an error message!

Example of a call: Read set point of encoder with addr. 6.

Command code	Param. index Low	Param. index High	Sub-index (= address)	Data byte 1	Data byte 2	Data byte 3	Data byte 4
40h	0Ah	5Fh	06h	00h	00h	00h	00h

Reply: Set point = 25000 (= 61A8h)

Command code	Param. index Low	Param. index High	Sub-index (= address)	Data byte 1	Data byte 2	Data byte 3	Data byte 4	Position values of the connected encoders		
42h	0Ah	5Fh	06h	A8h	61h	00h	00h		xxh	xxh

3.7.12 Switch on keyboard (SN3 protocol)

This parameter serves for switching on a keyboard (if available on the device). Data bytes 1 to 4 can have any content.

This command is broadcast-compatible (see [Table 2](#)). All SIKONETZ stations are addressed by setting bit 6 in the sub-index byte. If bit 6 is not set, a valid encoder address must be indicated in the sub-index byte.

Example of a call: The keyboards of all SIKONETZ stations are to be addressed. (The bits representing the address in the sub-index field may have any values!)

Command code	Param. index Low	Param. index High	Sub-index (= address)	Data byte 1	Data byte 2	Data byte 3	Data byte 4
23h	0Bh	5Fh	4xh	xxh	xxh	xxh	xxh

Reply:

Command code	Param. index Low	Param. index High	Sub-index (= address)	Data byte 1	Data byte 2	Data byte 3	Data byte 4	Position values of the connected encoders		
60h	0Bh	5Fh	4xh	xxh	xxh	xxh	xxh		xxh	xxh

3.7.13 Switch off keyboard (SN3 protocol)

This parameter serves for switching off a keyboard (if available on the device) (broadcast-compatible; see [Table 2](#)).

Example of a call: Switch off keyboard, device with address 02H.

Command code	Param. index Low	Param. index High	Sub-index (= address)	Data byte 1	Data byte 2	Data byte 3	Data byte 4
23h	0Ch	5Fh	02h	xxh	xxh	xxh	xxh

Reply:

Command code	Param. index Low	Param. index High	Sub-index (= address)	Data byte 1	Data byte 2	Data byte 3	Data byte 4	Position values of the connected encoders		
60h	0Ch	5Fh	02h	xxh	xxh	xxh	xxh		xxh	xxh

3.7.14 Start positioning (SN3 protocol)

This command is used in connection with SIKONETZ stations that are able to execute positioning in order to travel to a desired position defined by the Set point command described above. The content of user data bytes 1 ... 4 is irrelevant.

Example of a call: Start positioning, device with addr. 23(= 17h).

Command code	Param. index Low	Param. index High	Sub-index (= address)	Data byte 1	Data byte 2	Data byte 3	Data byte 4
23h	0Dh	5Fh	17h	xxh	xxh	xxh	xxh

Reply:

Command code	Param. index Low	Param. index High	Sub-index (= address)	Data byte 1	Data byte 2	Data byte 3	Data byte 4	Position values of the connected encoders		
60h	0Dh	5Fh	17h	xxh	xxh	xxh	xxh		xxh	xxh

3.7.15 Stop positioning (SN3 protocol)

This command stops a positioning job previously started. The content of user bytes 1 ... 4 is irrelevant (broadcast-compatible; see [Table 2](#)).

Example of a call: Stop positioning; all SIKONETZ devices are addressed independent of the address entered in the sub-index field.

Command code	Param. index Low	Param. index High	Sub-index (= address)	Data byte 1	Data byte 2	Data byte 3	Data byte 4
23h	0Eh	5Fh	4xh	xxh	xxh	xxh	xxh

Reply:

Command code	Param. index Low	Param. index High	Sub-index (= address)	Data byte 1	Data byte 2	Data byte 3	Data byte 4	Position values of the connected encoders		
60h	0Eh	5Fh	4xh	xxh	xxh	xxh	xxh		xxh	xxh

3.7.16 Switch on display (SN3 protocol)

This command serves for switching on the display of devices that have a display unit. The content of user bytes 1 ... 4 is irrelevant (broadcast-compatible; see [Table 2](#)).

Example of a call: Switch on display; all SIKONETZ devices are addressed independent of the address entered in the sub-index field.

Command code	Param. index Low	Param. index High	Sub-index (= address)	Data byte 1	Data byte 2	Data byte 3	Data byte 4
23h	0Fh	5Fh	4xh	xxh	xxh	xxh	xxh

Reply:

Command code	Param. index Low	Param. index High	Sub-index (= address)	Data byte 1	Data byte 2	Data byte 3	Data byte 4	Position values of the connected encoders	
60h	0Fh	5Fh	4xh	xxh	xxh	xxh	xxh		xxh xxh

3.7.17 Switch off display (SN3 protocol)

This command serves for switching off the display of devices that have a display unit. The content of user bytes 1 ... 4 is irrelevant (broadcast-compatible; see [Table 2](#)).

Example of a call: Switch off display, all SIKONETZ devices are addressed independent of the address entered in the sub-index field.

Command code	Param. index Low	Param. index High	Sub-index (= address)	Data byte 1	Data byte 2	Data byte 3	Data byte 4
23h	10h	5Fh	4xh	xxh	xxh	xxh	xxh

Reply:

Command code	Param. index Low	Param. index High	Sub-index (= address)	Data byte 1	Data byte 2	Data byte 3	Data byte 4	Position values of the connected encoders	
60h	10h	5Fh	4xh	xxh	xxh	xxh	xxh		xxh xxh

3.7.18 Set sense of rotation (SN4 protocol)

This command serves for parameterizing the sense of rotation (counting direction) of the selected encoder. The content of data byte 1 is relevant only. The content of data byte 1 has the following meaning:

01h = clockwise sense of rotation or "descending" counting direction

00h = counterclockwise sense of rotation or "ascending" counting direction

Example of a call: The sense of rotation of the encoder with address 21 (15h) is to be set so that it delivers ascending position values with clockwise rotation.

Command code	Param. index Low	Param. index High	Sub-index (= address)	Data byte 1	Data byte 2	Data byte 3	Data byte 4
23h	11h	5Fh	15h	01h	xxh	xxh	xxh

Reply:

Command code	Param. index Low	Param. index High	Sub-index (= address)	Data byte 1	Data byte 2	Data byte 3	Data byte 4	Position values of the connected encoders	
60h	11h	5Fh	15h	00h	00h	00h	00h		xxh xxh

3.7.19 Read/program InPos window (SN3 protocol)

This command serves for reading or programming the window showing the deviation of actual value from set point.

Value range: -9999 ... +9999

Example of a call: The InPos window of the encoder with address 21 (15) shall be set to value 25.

Command code	Param. index Low	Param. index High	Sub-index (= address)	Data byte 1	Data byte 2	Data byte 3	Data byte 4
23h	11h	5Fh	15h	19h	xxh	xxh	xxh

Reply:

Command code	Param. index Low	Param. index High	Sub-index (= address)	Data byte 1	Data byte 2	Data byte 3	Data byte 4	Position values of the connected encoders	
60h	11h	5Fh	15h	19h	xxh	xxh	xxh		xxh xxh

3.7.20 Read/program the loop reversal point

This command serves for reading or programming the loop reversal point (in display units).

Value range: -9999 ... +9999

Example of a call: The loop reversal point of the encoder with address 14 (10h) shall be set to value 50.

Command code	Param. index Low	Param. index High	Sub-index (= address)	Data byte 1	Data byte 2	Data byte 3	Data byte 4
23h	12h	5Fh	0Eh	32h	xxh	xxh	xxh

Reply:

Command code	Param. index Low	Param. index High	Sub-index (= address)	Data byte 1	Data byte 2	Data byte 3	Data byte 4	Position values of the connected encoders	
60h	12h	5Fh	0Eh	32h	xxh	xxh	xxh		xxh xxh

3.7.21 Read device code (SN3 protocol)

NOTICE	The firmware version coding of the AP05-SW06 device differ from that of the other SN3 devices. Examples: AP05-SW06: V1.04 = 104 = 68h MSA111C (MSA501): V1.02 = 12h
---------------	---

This command serves for reading the device code, the firmware version as well as the hardware status of the addressed encoder.

Example of a call: The device code of the encoder with address 10 (0Ah) shall be read.

Command code	Param. index Low	Param. index High	Sub-index (= address)	Data byte 1	Data byte 2	Data byte 3	Data byte 4
40h	13h	5Fh	0Ah	xxh	xxh	xxh	xxh

Reply:

Command code	Param. index Low	Param. index High	Sub-index (= address)	Data byte 1	Data byte 2	Data byte 3	Data byte 4	Position values of the connected encoders	
42h	13h	5Fh	0Ah	22h	11h	10h	00h	xxh	xxh

Data byte 1: 22h ⇒ Code of SIKO device MSA501-SN3

Data byte 2: 11h ⇒ Firmware version V1.01

Data byte 3: 10h ⇒ Hardware version V1.0

For the numerical values of the device codes please refer to the relevant User information of the devices concerned.

3.7.22 Read/program decimal places

3.7.22.1 Devices with SN4 protocol

This command enables programming of decimal places for devices that have a display unit. SN devices that have no display unit respond to this command with an error message.

Value range: 0 ... 4

00h = display format XXXXX.

01h = display format XXXX.X

02h = display format XXX.XX

03h = display format XX.XXX

04h = display format X.XXXX

Example of a call: The position value shall be displayed with 3 decimal places in the encoder with address 2 (02h).

Command code	Param. index Low	Param. index High	Sub-index (= address)	Data byte 1	Data byte 2	Data byte 3	Data byte 4
23h	12h	5Fh	02h	03h	xxh	xxh	xxh

Reply:

Command code	Param. index Low	Param. index High	Sub-index (= address)	Data byte 1	Data byte 2	Data byte 3	Data byte 4	Position values of the connected encoders	
60h	12h	5Fh	02h	00h	00h	00h	00h	xxh	xxh

3.7.22.2 Devices with SN3 protocol

NOTICE

Take care that you enter the numerical value representing the decimal places at the position of data byte 2!

This command enables reading or programming of decimal places for devices that have a display unit. SN3 devices that have no display unit respond to this command with an error message.

Value range: 0 ... 4

Example of a call: 3 decimal places shall be displayed on an AP05-SW06 (device address 30).

Command code	Param. index Low	Param. index High	Sub-index (= address)	Data byte 1	Data byte 2	Data byte 3	Data byte 4
23h	14h	5Fh	1Eh	00h	03h	00h	xxh

Reply:

Command code	Param. index Low	Param. index High	Sub-index (= address)	Data byte 1	Data byte 2	Data byte 3	Data byte 4	Position values of the connected encoders	
60h	14h	5Fh	1Eh	00h	00h	00h	00h	xxh	xxh

If this command is applied in reading, the encoder will return the encoder address of the addressed device in addition to the number of decimal places:

Command code	Param. index Low	Param. index High	Sub-index (= address)	Data byte 1	Data byte 2	Data byte 3	Data byte 4
40h	14h	5Fh	1Eh	00h	03h	00h	xxh

Reply:

Command code	Param. index Low	Param. index High	Sub-index (= address)	Data byte 1	Data byte 2	Data byte 3	Data byte 4	Position values of the connected encoders	
42h	14h	5Fh	1Eh	1Eh	03h	00h	00h	xxh	xxh

Data byte 1: Encoder address (1Eh = address 31)

Data byte 2: Number of decimal places (03h = 3 decimal places)

Attempts to apply the "Program decimal places" command to a device with no display unit will cause the gateway to return the following response (Example: Encoder address 26):

Command code	Param. index Low	Param. index High	Sub-index (= address)	Data byte 1	Data byte 2	Data byte 3	Data byte 4	Position values of the connected encoders		
80h	14h	5Fh	1Ah	06h	08h	83h	00h		xxh	xxh

Data bytes 1 and 2: Error code 0806h ⇒ SIKONETZ3 error

Data byte 3: Error message 83h ⇒ illegal command (see also chapter 4.1)

3.7.23 Enable key's incremental measurement function (SN3 protocol)

This command enables the incremental measurement function of the addressed encoder's key.

Value range: The content of data bytes 1 ... 4 is irrelevant

Example of a call: The key's incremental measurement function is enabled for an AP05-SW06 (device address 29).

Command code	Param. index Low	Param. index High	Sub-index (= address)	Data byte 1	Data byte 2	Data byte 3	Data byte 4
23h	15h	5Fh	1Dh	xxh	xxh	xxh	xxh

Reply:

Command code	Param. index Low	Param. index High	Sub-index (= address)	Data byte 1	Data byte 2	Data byte 3	Data byte 4	Position values of the connected encoders		
60h	15h	5Fh	1Dh	00h	00h	00h	00h		xxh	xxh

3.7.24 Disable key's incremental measurement function (SN3 protocol)

This command disables the incremental measurement function of the addressed encoder's key.

Value range: The content of data bytes 1 ... 4 is irrelevant

Example of a call: The key's incremental measurement function is disabled for an AP05-SW06 (device address 29).

Command code	Param. index Low	Param. index High	Sub-index (= address)	Data byte 1	Data byte 2	Data byte 3	Data byte 4
23h	16h	5Fh	1Dh	xxh	xxh	xxh	xxh

Reply:

Command code	Param. index Low	Param. index High	Sub-index (= address)	Data byte 1	Data byte 2	Data byte 3	Data byte 4	Position values of the connected encoders		
60h	16h	5Fh	1Dh	00h	00h	00h	00h		xxh	xxh

3.7.25 Display divisor

3.7.25.1 Write with SN4 protocol

This parameter serves for reducing by the selected factor the resolution indicated on the display unit. Example: The measurement resolution of the measuring system consisting of rotary encoder AP05-SW06 and spindle has been parameterized to a resolution of 1/1000 mm. However, a resolution of 1/10 mm is sufficient for the representation of the measured value on the display unit. Therefore, the display divisor is set to the value 100.

The content of data byte 1 is relevant only. The content of data byte 1 has the following meaning:

Value range: 0 ... 3

0: ADI = 1

1: ADI = 10

2: ADI = 100

3: ADI = 1000

Example of a call: The display divisor shall be set for the encoder with address 17 (11h).

Command code	Param. index Low	Param. index High	Sub-index (= address)	Data byte 1	Data byte 2	Data byte 3	Data byte 4
23h	13h	5Fh	11h	02h	xxh	xxh	xxh

Reply:

Command code	Param. index Low	Param. index High	Sub-index (= address)	Data byte 1	Data byte 2	Data byte 3	Data byte 4	Position values of the connected encoders	
60h	13h	5Fh	02h	00h	00h	00h	00h	xxh	xxh

3.7.25.2 Read/write with SN3 protocol

This parameter serves for programming the display divisor (DDI). This influences the representation of the numerical value on the display unit of the addressed encoder. The value set for the display divisor can be read via the read function.

The command is only valid for devices that have a display unit. The command will be acknowledged with an error message if the device addressed does not recognize this command.

Value range: 0 ... 3

0: ADI = 1

1: ADI = 10

2: ADI = 100

3: ADI = 1000

Example of a call: The DDI value 10 is programmed for an AP05-SW06 (device address 6).

Command code	Param. index Low	Param. index High	Sub-index (= address)	Data byte 1	Data byte 2	Data byte 3	Data byte 4
23h	17h	5Fh	06h	01h	xxh	xxh	xxh

Reply:

Command code	Param. index Low	Param. index High	Sub-index (= address)	Data byte 1	Data byte 2	Data byte 3	Data byte 4	Position values of the connected encoders	
60h	17h	5Fh	06h	00h	00h	00h	00h	xxh	xxh

3.7.26 Loop approach direction

3.7.26.1 Write with SN4 protocol

This command serves for setting the loop approach direction of the selected encoder. For more detailed information on loop travel please refer to the User information of the AP05-SW06 devices, respectively.

The content of data byte 1 is relevant only. Data byte 1 can be set to the following value, different values trigger an error message:

Value range: 0 ... 2

0: direct

1: clockwise

2: counterclockwise

Example of a call: "Counterclockwise" loop approach direction shall be set for the encoder with address 7 (07h).

Command code	Param. index Low	Param. index High	Sub-index (= address)	Data byte 1	Data byte 2	Data byte 3	Data byte 4
23h	14h	5Fh	07h	02h	xxh	xxh	xxh

Reply:

Command code	Param. index Low	Param. index High	Sub-index (= address)	Data byte 1	Data byte 2	Data byte 3	Data byte 4	Position values of the connected encoders	
60h	14h	5Fh	07h	00h	00h	00h	00h	xxh	xxh

3.7.26.2 Read/write with SN3 protocol

This command serves for reading or programming the loop approach direction.

Value range: 0 ... 2

0: direct

1: clockwise

2: counterclockwise

Example of a call: "Clockwise" loop approach direction shall be programmed for an AP05-SW06 (device address 1).

Command code	Param. index Low	Param. index High	Sub-index (= address)	Data byte 1	Data byte 2	Data byte 3	Data byte 4
23h	18h	5Fh	01h	01h	xxh	xxh	xxh

Reply:

Command code	Param. index Low	Param. index High	Sub-index (= address)	Data byte 1	Data byte 2	Data byte 3	Data byte 4	Position values of the connected encoders	
60h	18h	5Fh	01h	00h	00h	00h	00h	xxh	xxh

3.7.27 Read/program Zeroing enable (SN3 protocol)

This command enables or disables the addressed device's key for the zeroing function. The key's status can also be queried.

With the function enabled, actuating the key sets the position value to the value "calibration value + offset value". If the two above-mentioned values are set to 0, pressing the key will result in "zeroing" of the display.

Value range: 0 ... 1

0: Zeroing disabled

1: Zeroing enabled

Example of a call: "Counterclockwise" loop approach direction shall be programmed for an AP05-SW06 (device address 1).

Command code	Param. index Low	Param. index High	Sub-index (= address)	Data byte 1	Data byte 2	Data byte 3	Data byte 4
23h	19h	5Fh	01h	02h	xxh	xxh	xxh

Reply:

Command code	Param. index Low	Param. index High	Sub-index (= address)	Data byte 1	Data byte 2	Data byte 3	Data byte 4	Position values of the connected encoders	
60h	19h	5Fh	01h	00h	00h	00h	00h	xxh	xxh

3.7.28 Write display orientation (SN4 protocol)

This command serves for aligning the display of the selected encoder.

The content of data byte 1 is relevant only. Data byte 1 can be set to the following value, different values trigger an error message:

Value range: 0 ... 1

0: Display orientation 0°

1: Display orientation 180°

Example of a call: The display orientation shall be set to 180° for the encoder with address 11 (0Bh).

Command code	Param. index Low	Param. index High	Sub-index (= address)	Data byte 1	Data byte 2	Data byte 3	Data byte 4
23h	15h	5Fh	0Bh	01h	xxh	xxh	xxh

Reply:


Command code	Param. index Low	Param. index High	Sub-index (= address)	Data byte 1	Data byte 2	Data byte 3	Data byte 4	Position values of the connected encoders	
60h	15h	5Fh	0Bh	00h	00h	00h	00h	xxh	xxh

3.7.29 Read/program display orientation and LED functionality (SN3 protocol)

NOTICE	Bits 0 ... 3 in data byte 2 are saved non-volatily. For setting bits 4 and 5, target window dependence (bits 0 and 1) must be deactivated.
---------------	--

This command serves for influencing or determining the display orientation and LED functionality of the AP05-SW06 device.

The values obtained in data bytes 1 and 2 with a read access inform on the current states of display orientation and LED functionality:



Example of a call: On the AP05-SW06 (device address 2), the status of display orientation and the LED statuses shall be read.

Command code	Param. index Low	Param. index High	Sub-index (= address)	Data byte 1	Data byte 2	Data byte 3	Data byte 4
40h	1Ah	5Fh	02h	xxh	xxh	xxh	xxh

Reply:

Command code	Param. index Low	Param. index High	Sub-index (= address)	Data byte 1	Data byte 2	Data byte 3	Data byte 4	Position values of the connected encoders	
42h	1Ah	5Fh	02h	01h	01h	00h	00h	xxh	xxh

Result:

Data byte 1 = 1 ⇒ display orientation = 180°

Data byte 2 = 1 ⇒ LED green = ON if position value within the target window

3.7.30 Enable key function (SN4 protocol)

This command assigns a particular function to the key(s) of encoder AP05-SW06, resp. The functionality is influenced via data byte 1. This byte may assume the following values:

00h: the key has no function

01h: the key is enabled for the incremental measurement function

02h: the key is enabled for the reset function

03h: no influence (only present for compatibility reasons)

Example of a call: The "Reset" key function shall be set for the encoder with address 12 (0Bh).

Command code	Param. index Low	Param. index High	Sub-index (= address)	Data byte 1	Data byte 2	Data byte 3	Data byte 4
23h	16h	5Fh	0Ch	02h	xxh	xxh	xxh

Reply:

Command code	Param. index Low	Param. index High	Sub-index (= address)	Data byte 1	Data byte 2	Data byte 3	Data byte 4	Position values of the connected encoders	
60h	16h	5Fh	0Ch	00h	00h	00h	00h	xxh	xxh

3.7.31 Incremental measurement and Reset key functions (SN4 protocol)

The "Incremental measurement" and "Reset" key functions of the AP05-SW06 can be enabled or disabled simultaneously by means of this command. The necessary parameter is provided in data byte 1. Data bytes 2 ... 4 are irrelevant.

The following values are valid:

00h: "Incremental measurement and Reset" function disabled

01h: "Incremental measurement and Reset" function enabled

Example of a call: The "Enable Incremental measurement and Reset" key function shall be set for the encoder with address 15 (0Fh).

Command code	Param. index Low	Param. index High	Sub-index (= address)	Data byte 1	Data byte 2	Data byte 3	Data byte 4
23h	17h	5Fh	0Fh	01h	xxh	xxh	xxh

Reply:

Command code	Param. index Low	Param. index High	Sub-index (= address)	Data byte 1	Data byte 2	Data byte 3	Data byte 4	Position values of the connected encoders	
60h	17h	5Fh	0Fh	00h	00h	00h	00h	xxh	xxh

4 Trouble shooting

4.1 Error indication via status bytes

In case an error has occurred (illegal command index, illegal address, illegal access, e. g. Write request to read variable or communication error between IF09P/1 and the encoders), an error response and a corresponding error number in the user data byte will be returned instead of a Write or Read response.

Command code	Data byte 3	Data byte 4	Meaning
80h	8	6	SIKONETZ error
80h	7	6	Wrong parameter
80h	6	6	Wrong index
80h	5	6	Wrong sub-index (= SIKONETZ address)
80h	3	6	Access rejected, e. g. Write request to Read variable or parameter not available.
80h	4	6	Broadcast not allowed with this command.
80h	1	6	Communication error between IF09P/1 and RS485 bus (connection down or checksum error)

Example: Write parameter Display per revolution on device with address higher 31, e. g. 72 (= 48h).

Command code	Param. index Low	Param. index High	Sub-index (= address)	Data byte 1	Data byte 2	Data byte 3	Data byte 4
23h	05h	5Fh	48h	00h	20h	00h	00h

Reply: Error response, wrong sub-index (= wrong address)

Command code	Param. index Low	Param. index High	Sub-index (= address)	Data byte 1	Data byte 2	Data byte 3	Data byte 4	Position values of the connected encoders	
80h	05h	5Fh	48h	00h	00h	05h	06h	xxh	xxh

The error message with code 80h in the command code field is maintained until the command has been executed with the correct parameters.

Upon application of the SN3 protocol, an addressed SN3 station will response with an error message in case of faulty parameterization. This code is transferred in data byte 2 in addition to data bytes 3 and 4.

Example:

Command code	Param. index Low	Param. index High	Sub-index (= address)	Data byte 1	Data byte 2	Data byte 3	Data byte 4	Position values of the connected encoders	
80h	05h	5Fh	48h	00h	83h	05h	06h	xxh	xxh

Meaning of the SN3 error codes:

- 82h: Error code F02; data transfer error (checksum error)
- 83h: Error code F03; illegal or unknown command

- 85h: Error code F05; illegal value input


The error code appears also on the 5-digit display of the IF09P/1 for a short time.

4.2 Error representation on the display

Errors in data transfer between IF09P/1 and the connected encoders are indicated by a red blinking LED and as plain text on the 5-digit 7-segment display.

Two error types are differentiated: Time-out errors and checksum errors. Time-out errors indicate that the connection to the addressed encoder is down or that the encoder is defective. Checksum errors occur in a disturbed environment, e. g., if two or more encoders are operated with the identical address on the same bus.

In case of error, the error type (time-out or checksum error) and the address of the disturbed encoder are output on the display. Both values are alternately output on the display (example: faulty encoder with address 19).





SIKO GmbH

Weihermattenweg 2
79256 Buchenbach

Phone

+ 49 7661 394-0

Fax

+ 49 7661 394-388

E-Mail

info@siko-global.com

Internet

www.siko-global.com

Service

support@siko-global.com